

WHITE POOL TILE GROUT

E-Z INSTRUCTIONS:

- 1. Lower pool water to 6" below the repair area.
- 2. Remove all loose material or grout.
- 3. Add LIQUID CEMENT BONDER to **E-Z PATCH 4®** DRY CEMENT MIX (use fractions = ¼ of the dry mix to ¼ of the liquid cement bonder, etc.). Add water and mix (stir) until you get the consistency of "mashed potatoes".
- **4.** Completely fill area to be grouted and allow to partially dry (approx. 5 min.).
- **5.** Using a damp sponge, lightly wipe off excess grout leaving joint full and flush. Rinse sponge often.
- **6.** When grout is dry, polish residual "haze" off with a dry, clean cloth taking care to keep the cloth dry during this polishing period.

You may refill water the next day

To make a Custom Color with any of our cement type repair supplies, use any cement dye.

View our instructional repair video showing how to do this repair at www.e-zpatch.com

E-Z ANSWERS to some Frequently Asked Questions

- Liquid Bonder is inside the jar
- Product will cure faster in hotter weather, slower in cooler weather
- Product is best stored between 40 degrees F and 90 degrees F

<u>WARNING:</u> CONTAINS CEMENT, AN ALKALINE SUBSTANCE IRRITATING TO EYES AND SKIN. CONTAINS ETHYLENE ACETATE CEMENT BONDER. SHOULD PRODUCT CONTACT EYES, FLUSH THEM IMMEDIATELY AND REPEATEDLY WITH WATER AND CALL A PHYSICIAN. DO NOT TAKE INTERNALLY. IN CASE OF SKIN CONTACT, RINSE IMMEDIATELY WITH WATER. USE OF RUBBER GLOVES IS RECOMMENDED.

KEEP OUT OF THE REACH OF CHILDREN