



WHITE POOL COPING STONE REPAIR

Description: E-Z Patch® 5 (White) Coping Stone Repair allows you to repair cracks, chips or large missing chunks on coping stones. This product contains special acrylic modified materials with pozzolans (siliceous volcanic ash) and polymers. After product application, swimming may be allowed the next day.

Before mixing and applying the repair material, make sure it is the right color and material match! It is sometimes hard to see exactly what the color will be from computer monitor screens.

Take a small amount of dry material out of the repair kit and mix with water to be the consistency of "Putty". Then, wet the existing surface that you are trying to match and compare the wet sample to the wet existing surface. If the material needs to be darker, add a very small amount of E-Z Patch Black Cement Dye and dry mix well. If the material needs to be lighter, add a very small amount of E-Z Patch Titanium Dioxide White Cement Colorant and dry mix well. Both colors are available on our website. You can also use any good cement dye. Repeat this process until the color match is satisfactory

E-Z INSTRUCTIONS:

1. Remove any loose pieces.
2. Scrub area with water and brush using muriatic acid or powdered laundry detergent if needed.
3. Immediately rinse the area thoroughly and allow to dry until slightly damp.
4. **FOR RESETTING PIECES OF COPING STONE:** Use E-Z PATCH® 3 (Thinset). Apply some to each piece and press into place firmly.
5. Add LIQUID CEMENT BONDER to **E-Z PATCH® 5 DRY CEMENT MIX** (use fractions = $\frac{1}{4}$ of the dry mix to $\frac{1}{4}$ of the liquid cement bonder, etc.). Add water and mix until you get the consistency of very stiff "mashed potatoes". Use warm water for faster set and cold water to slow set.
- 6a. **FOR CHIP REPAIR:** Apply one thin "scratch coat" of **E-Z PATCH® 5** and then fill the area full. Trowel it fairly smooth and flat. Immediately remove excess from edges with a moist sponge. For larger areas apply a little extra **E-Z PATCH® 5** without troweling flat and smooth. Wait about 15 min. until firm and then, using a trowel, scrape off excess. If needed, use a nail, etc. to make the older style

coping stone pattern by pressing into fresh repair 1/8" deep. Now immediately trowel the area again flat and smooth with a clean moist trowel for finish.

6b. FOR CRACK OR GROUT REPAIRS: Rub **E-Z PATCH® 5** deep into the crack or coping grout joint and remove any excess with a moist sponge.

Allow to dry overnight before swimming.

To make a Custom Color with any of our cement type repair supplies, use any cement dye. View our instructional repair video showing how to do this repair at www.e-zpatch.com

E-Z ANSWERS to some Frequently Asked Questions

- **Liquid Bonder is inside the jar**
- **Product will cure faster in hotter weather, slower in cooler weather**
- **Product is best stored between 40 degrees F and 90 degrees F**

WARNING: CONTAINS CEMENT, AN ALKALINE SUBSTANCE IRRITATING TO EYES AND SKIN. CONTAINS ACRYLIC RESIN CEMENT BINDER. SHOULD PRODUCT CONTACT EYES, FLUSH THEM IMMEDIATELY AND REPEATEDLY WITH WATER AND CALL A PHYSICIAN. DO NOT TAKE INTERNALLY. IN CASE OF SKIN CONTACT, RINSE IMMEDIATELY WITH WATER. USE OF RUBBER GLOVES IS RECOMMENDED.

KEEP OUT OF THE REACH OF CHILDREN