



## WHITE POOL COPING STONE REPAIR

### E-Z INSTRUCTIONS:

1. Remove any loose pieces.
2. Scrub area with water and brush using muriatic acid or powdered laundry detergent if needed.
3. Immediately rinse the area thoroughly and allow to dry until slightly damp.
4. **FOR RESETTING PIECES OF COPING STONE:** Use E-Z PATCH® 3 (Thinset) OR FOR A FLEXIBLE REPAIR dry the surfaces completely and use E-Z PATCH® 22 NEUTRAL CURE SILICONE RUBBER. Apply some to each piece and press into place firmly.
5. Add LIQUID CEMENT BONDER to **E-Z PATCH® 5 DRY CEMENT MIX** (use fractions = ¼ of the dry mix to ¼ of the liquid cement bonder, etc.). Add water and mix until you get the consistency of very stiff “mashed potatoes”. Use warm water for faster set and cold water to slow set.
- 6a. **FOR CHIP REPAIR:** Apply one thin “scratch coat” of **E-Z PATCH® 5** and then fill the area full. Trowel it fairly smooth and flat. Immediately remove excess from edges with a moist sponge. For larger gaps apply a little extra **E-Z PATCH® 5** without troweling flat and smooth. Wait 15 to 30 min. until very firm and then, using a trowel or any flat piece of metal or wood, scrape off excess. Using a nail, etc. make coping stone pattern by pressing into fresh repair 1/8” deep. Trowel area again flat and smooth with a clean moist trowel for finish.
- 6b. **FOR CRACK OR GROUT REPAIRS:** Rub **E-Z PATCH® 5** deep into crack and remove any excess with a moist sponge.

Allow to dry overnight before swimming.

To make a Custom Color with any of our cement type repair supplies, use any cement dye.

View our instructional repair video showing how to do this repair at [www.e-zpatch.com](http://www.e-zpatch.com)

### E-Z ANSWERS to some Frequently Asked Questions

- Liquid Bonder is inside the jar
- Product will cure faster in hotter weather, slower in cooler weather
- Product is best stored between 40 degrees F and 90 degrees F

**WARNING:** CONTAINS CEMENT, AN ALKALINE SUBSTANCE IRRITATING TO EYES AND SKIN. CONTAINS ACRYLIC RESIN CEMENT BINDER. SHOULD PRODUCT CONTACT EYES, FLUSH THEM IMMEDIATELY AND REPEATEDLY WITH WATER AND CALL A PHYSICIAN. DO NOT TAKE INTERNALLY. IN CASE OF SKIN CONTACT, RINSE IMMEDIATELY WITH WATER. USE OF RUBBER GLOVES IS RECOMMENDED.

**KEEP OUT OF THE REACH OF CHILDREN**